
INNOLUME

LD-1120-BF-200 Fiber Coupled High Power Laser Diode – 200mW @1120nm ex-fiber				
innoume	Features: InAs/GaAs Quantum Well based Proprietary mirror coating techno CW or pulse (down to 2ns pulse High reliable Au/Sn-technology Optional: polarization maintaining Optional: integrated monitor phot	diode laser logy enabling high reliability width) operation g PM980 fiber odiode for power control		
h .	Specification	DATE: 18 th June 2010		


SPECIFICATIONS Test conditions: CW operation, thermistor temperature 25°C					
Parameters	Symb.	Min.	Тур.	Max.	Unit
Output power	P _{out}	200			mW
Mean wavelength at Pout ¹	λ _P	1110	1120	1130	nm
Spectral width @ -3dB level at Pout	Δλ		4	8	nm
Wavelength temperature tunability	Δλ/ΔΤ	0.35	0.4	0.45	nm / °C
Threshold current	l _{th}		80	120	mA
Operating current at Pout	I _{op}		500	600	mA
Forward voltage at Pout	V _f		1.4	1.5	V
Polarization Extinction Ratio ²	PER	15	17		dB
Recommended operating temperature (on thermistor)	T _{op}	15	25	30	°C

¹ Weighted mean ("center of mass") spectral point. ² In the case of polarization maintaining fiber.



INNOLUME

ABSOLUTE MAXIMUM RATINGS						
Parameters	Min.	Max.	Unit			
Laser Diode reverse voltage		1	V			
Laser Diode CW forward current		1000	mA			
Thermo Electric Cooler current		3	A			
Thermo Electric Cooler voltage		4	V			
Storage temperature range (in original sealed pack)	5	80	°C			
Case operating temperature range	10	50	°C			



FIBER SPECIFICATION						
Parameters	HI1060	PANDA PM980	Unit			
Numerical aperture (Typical)	0.14	0.14				
Cutoff wavelength	920±50	920±50	nm			
Mode-field diameter (@1060nm)	6.2±0.3	6.6±0.3	μm			
Cladding diameter	125±1	125±1	μm			
Coating diameter	245±15	245±15				
Length	1.0 ± 0.1		m			
Connector	FC/APC connector					
FAST AXIS						

SAFETY AND OPERATING INSTRUCTIONS

The laser light emitted from this device is invisible and will be harmful to the human eye. Avoid looking directly into the output fiber or into the collimated beam along its optical axis when the device is in operation. Proper laser safety eyewear must be worn during operation.

Operating the laser diode outside of its maximum ratings may cause device failure or a safety hazard. Power supplies used with the component must be employed such that the maximum forward current cannot be exceeded. A proper heatsink for the laser diode module on thermal radiator is required. The module must be mounted on radiator with screws (bolt down in X-style fashion with initial torque set to 0.075Nm and final X-style bolt down at 0.15Nm) or clamps. The deviation from flatness of radiator surface must be less than 0.05mm. It's recommended using of In-foil or similar between bottom of the module and heatsink for thermal interface.

Carefully handle the fragile fiber, do not apply any stress, do not pull the fiber, do not bend fiber with a radius smaller than 3cm. Operate the laser module with clean fiber connector only. Periodically check and clean the connector if necessary. To clean the connector use suitable fiber cleaning tools (e.g. special cleaning tissue for optics). Perform cleaning only while the laser is switched off. Protect the fiber connector with protection cap while it's unplugged.

ESD PROTECTION – Electrostatic discharge is the primary cause of unexpected Laser Diode failure. Take extreme precaution to prevent ESD. Use wrist straps, grounded work surfaces and rigorous antistatic techniques when handling laser diodes.



NOTE: Innolume product specifications are subject to change without notice.